




Included Components:

- A. 1x LockVise™ Metal Locking Holder w/hardware (TAB004KL)**
- B. 1x 4" Pedestal w/ hardware (RMS2XAMPS-MET-SH)**
- 1x Quick Charge Power Adapter w/ In-Line Fuse (CAFIQC3)**
- 1x 240W Magnetic Type-C Cable (CAMAG240CADP)**


Please note the hardware included with the tablet holder:

4 × M4 12mm screws, 4 × M4 hex nuts, 1 × T20 Torx bit, 2 × foam pads, 1 × set of locking keys, 1 × security knob.


Notes:

- **Important:** Clean the mounting surface before installation. Make sure it is free of dirt, dust, and grease.


- 1** To remove the AMPS adapter plate from the pedestal, turn the shaft knob counterclockwise until they separate.




- 2** Remove the AMPS plate from the pedestal, align the AMPS adapter plate on the holder's back, then insert and tighten the four screws to secure it.



- 3** For mount installation, align screws (not included) with the AMPS adapter to secure the pedestal. Detach the shaft from the adapter if needed to simplify the process.



- 4** Assemble the components by turning the adjustment knob counterclockwise to expand, inserting the 25mm ball ends into the shaft, and then tightening by turning clockwise.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system


WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.




Tablet Holder Installation Steps:


- 1 Adjust Tablet Holder Width:** Loosen the bottom side screws, set the desired width, then tighten to secure the tablet.




- 2 Adjust Tablet Holder Length:** Loosen the three center-back screws, set the height, then retighten.



- 3 Secure the Tablet:** Press down the top locking arm, then use the included keys to lock it in place.



- 4 Optional – Foam Padding (no case):** Apply the foam pads to the inner sides of the holder for a secure fit.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

